

It is suggested to keep your projector running with up-to-date benefits from features, applications, and bug improvement. For more details about firmware update instruction and improvements, please read through the following:

Details and Feature Improvements for USB-C firmware

- Improve audio for surround sound mode on Nintendo SWITCH

How to update USB-C firmware on BenQ GV50 projector

Required tools and materials


USB-C firmware upgrade tool for GV50

USB-A to USB-C cable (with data transferring available)

BenQ GV50 projector


Step 1:

Operate the USB-C firmware upgrade tool




Step 2:

Turn off GV50, and connect GV50 and your laptop with a USB-A to USB-C cable (data transferring available required) as the following picture




You would see the picture below.




Step 4:

Click **Update**




Step 5:

Click **OK** to update USB-C firmware




Step 6:

Update in process




Step 7:

Click **OK** to complete the process



Step 8:

Unplug and plug the cable to check USB-C firmware version again; you would see the following picture as the following once firmware is updated successfully.



--- Document Ends ---