



Easy start
with videos

Digital Projector Quick Start Guide




Golf Simulator | AW30ST

BenQ PN: 4J.R0E01.001 V1.00

© 2025 BenQ Corporation. All rights reserved. Rights of modification reserved.




Package contents




Setup


1




2



3




4



5

Start setup




✓ All done. Enjoy!






Ceiling mounting

Screw type: M4 / Compatible BenQ ceiling mount: CM00G3



Golf Simulator 3D Planner



golfsimplanner.benq.com



a Lens to screen **b** Projector to floor **c** Tee position to launch monitor